

## Let's illuminate what your Smart Switch can do:

①

Create the perfect lighting scene for every occasion.

Go to the **CYNC App** and routines that matches the lighting to your mood.

②

Come home to the lights on at night.

Go to the **CYNC App**. Under scenes create a schedule that turns on your lights at the same time every night.

③

Control other bulbs and devices with your switch.

Go to the **CYNC App**. Add CYNC / C by GE bulbs, switches and plugs (sold separately) to the same room or group as your switch.

PK-00104348-4

Connect to your Alexa or Google Home device to control your lights with your voice.

Try these voice commands:

### Amazon Alexa

Alexa, turn off the living room.

Alexa, good morning.

### Google Home

Hey Google, turn on the lights.

Hey Google, I'm leaving.

## Touch Controls

### Toggle

On/Off

Toggling up or down turns lights on or off

Reset Button

Remove wall plate, use pin to press reset button

LED Indicator Light

### Paddle


LED Indicator Light

Reset Button

Remove wall plate, use pin to press reset button

On/Off

Pressing the bottom of the paddle turns lights on or off



## Voyons ce que votre interrupteur intelligent peut faire :

①

Créez la parfaite ambiance lumineuse pour chaque occasion.

Allez sur l'**application CYNC** et les routines qui correspondent à l'éclairage adapté à votre humeur.

②

Rentrez à la maison avec les lumières allumées la nuit.

Allez à l'**application CYNC**. Sous les ambiances, créez un horaire qui allume vos lumières à la même heure tous les soirs.

③

Contrôlez d'autres ampoules et dispositifs avec votre interrupteur.

Allez à l'**application CYNC**. Ajoutez des ampoules, des commutateurs et des prises CYNC / C by GE (vendus séparément) dans la même pièce ou le même groupe que votre interrupteur.

Connectez-vous à votre appareil Google Home ou Alexa pour contrôler vos appareils avec votre voix.

Essayez ces commandes vocales :

### Amazon Alexa

Alexa, éteins les lumières du salon.

Alexa, bonjour.

### Google Home

OK Google, allume les lumières.

OK Google, je pars.

## Commandes tactiles

### Basculer

Marche/Arrêt

Le basculement vers le haut ou le bas allume ou éteint les lumières

Bouton de réinitialisation

Retirez la plaque murale et utilisez une broche pour appuyer sur le bouton de réinitialisation

Voyant à DEL

### Palette

Voyant à DEL

Bouton de réinitialisation

Retirez la plaque murale et utilisez une broche pour appuyer sur le bouton de réinitialisation

Marche/Arrêt

Appuyer sur le bas de la palette allume ou éteint les lumières

